

BATTERY CHARGER

⚠ DANGER

- Do not charge the unit battery with the unit covered or enclosed. Any enclosure or cover should be removed or unzipped and pulled back when battery is being charged.

⚠ WARNING

- Only trained technicians should repair or service the charger. Contact your nearest authorized Club Car distributor/dealer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge. Children should be supervised to ensure that they do not play with the appliance.
- DO NOT operate the charger if it has received a sharp blow, was dropped, or otherwise damaged in any way. Have worn, cut, or damaged power cords or wires replaced immediately.
- Do not expose to rain or any liquid. Keep the charger dry.
- Do not connect the charger to a receptacle if the charger cord, plug, or the unit receptacle is broken, damaged, or does not make a good electrical connection. Fire or personal injury can result. Have a qualified technician replace any damaged parts.
- When the charger is on, the charger cord should be disconnected from the unit receptacle slowly. Jerking or pulling the charging cord out quickly could cause arcing and burning that could damage the plug and receptacle and could cause battery to explode.

⚠ WARNING

- Do not cover the charger. Do not allow clothing, blankets, or other material to cover the charger. The charger must dissipate heat and protect from overheating.

CAUTION

- The battery charger provided with this unit is approved for use only with the battery type originally shipped with the unit. Club Car only recommends OEM replacement battery. Contact your authorized Club Car dealer/distributor with any questions about battery and charger compatibility