

## Initial Tablet Setup

1. Power On Tablet (hold button on top left).
2. Select gear at the top right of operating instructions screen (Password: 6456 - Submit).
3. Select "Location Setup" from left column, and then type in the course name you want to find in the search box. Be patient it may take up to 60 seconds for the file to be located.
4. Select the desired course file that is displayed below the course search field (Hit Save, then ok).
5. Verify that this is done correctly
6. Select "Exit" tab from the left column when finished.
7. Press the "Start" button and hole selection to confirm tablet has been set up correctly.

*\*\*If you cannot locate the course file by name and/or city, reach out to your Club Car representative or search for the course at <https://skydroid.net/courses.php>.*

*If it is not preloaded, Club Car will need to map the course, which may take a couple days. When this is finished follow these instructions on how to download a file via WiFi.\*\**

## WiFi Download Method

1. Tap the Screen 7x quickly (use multiple fingers)
  - a. **Exit passcode 3897**
  - b. Press the "Stop Kiosk Mode" button (bottom middle)
  - c. Disable Kiosk Mode to confirm.
2. Select the 4x4 white grid icon on the bottom right of the screen. (All Applications)
3. Find and Select the Settings App
  - a. Navigate to the WiFi settings
  - b. **Connect to WiFi or your phone's mobile hotspot**
4. Press Tablet's Home button
5. Select the 4x4 white grid icon on the bottom right of the screen. (All Applications)
6. Find and Select the Fully Single App Kiosk
  - a. Select the "Start Kiosk Mode" button.
  - b. Disable Test Mode then select Yes.
  - c. Select Fully Single App Kiosk and Always for the default launcher
7. Within the Tempo Walk App
  - a. **Navigate to Gear Icon, then enter passcode 6456**
  - b. Select "Location Setup" tab on the left side.
    - i. When the data fields load, scroll to bottom of screen
    - ii. Press the "Download A Course" button
    - iii. Navigate to the correct course
      1. Note: This course will need to be mapped first, so contact Club Car contact to make sure this is completed.
    - iv. Select "Save" button on top of screen
      1. Press OK to confirm
  - c. Select "Exit" tab on the left side (you may need to scroll screen up to see this).
  - d. Verify that course file loaded correctly
    - i. Press Start button on Operating Instructions page
    - ii. Select 9/18 holes
    - iii. Verify course name is correct (top left)